# CDX-6020

SONY

# SERVICE MANUAL

*US Model*
*Canadian Model*
*E Model*

- Refer to CDX-R77 Service Manual previously issued for the information of this set.
- Following parts differ from those in CDX-R77.

| CDX-R77 | | CDX-6020 | |
|---|---|---|---|
| X-3339-415-2(Canadian, E)···PANEL ASSY, FRONT | | X-3339-430-1 | PANEL ASSY, FRONT |
| X-3339-418-1(US)·····PANEL ASSY, FRONT | | | |
| 3-750-025-21 | MANUAL INSTRUCTION | 3-751-443-21 | MANUAL INSTRUCTION |
| 3-750-034-21 | MANUAL INSTRUCTION | 3-751-444-21 | MANUAL INSTRUCTION |
| LABEL, MODEL NUMBER Not supplied | | *3-355-236-01 (US)·····LABEL, MODEL NUMBER | |
| | | *3-355-281-01 (Canadian)···LABEL, MODEL NUMBER | |
| | | *3-355-283-01 (E) ····· LABEL, MODEL NUMBER | |
| *3-345-347-01 | INDIVIDUAL CARTON | *3-355-234-01 | INDIVIDUAL CARTON |

**NOTE :**

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

## COMPACT DISC PLAYER

SONY

English
90A0433-1
Printed in Japan
© 1990. 1
Published by Customer Relations and Service Group

9-955-643-11

Sony Corporation
Mobile Electronics Group